



ΣΥΜΠΑΓΕΣ ΑΣΥΡΜΑΤΟ ΠΛΗΚΤΡΟΛΟΓΙΟ ΜΕ TOUCHPAD

GR Εγχειρίδιο χρήσης, Οδηγίες λειτουργίας και ασφάλειας και συνθήκες εγγύησης

EN User manual, Operating- and safety instructions and warranty conditions



ΣΥΜΠΑΓΕΣ ΚΑΙ ΜΟΝΤΕΡΝΟ ΠΛΗΚΤΡΟΛΟΓΙΟ ΜΕ 63 ΠΛΗΚΤΡΑ ΚΑΙ TOUCHPAD ΚΑΙ ΛΕΙΤΟΥΡΓΙΚΑ ΠΛΗΚΤΡΑ ΓΙΑ ΑΜΕΣΩΣ ΤΠΡΟΒΑΣΗ ΣΙΣ ΔΕΙΓΜΟΓΕΣ ΣΧΕΔΙΑΣΜΕΝΟ ΕΙΔΙΚΑ ΓΙΑ BLUETOOTH ΣΥΣΚΕΥΕΣ

Item no.: MROS130-GR

Η διάταξη του πληκτρολογίου που εμφανίζεται σε αυτό το εγχειρίδιο μπορεί να διαφέρει από το προϊόν της συσκευασίας.
Μπορείτε να ανταρτέστε στην ετικέτα της συσκευασίας για λεπτομέρειες.

EN Package contents

- 1x MediaRange Compact-sized wireless keyboard with 63 keys and touchpad, black
- 1x approx. 50cm USB-A to micro USB cable
- 1x User manual, Operating- and safety instructions and warranty conditions (DE/EN)

EN Operating- and safety instructions

Please read the following operation and safety instructions carefully before using this product to ensure safe and proper use. If these instructions are not followed, you may damage this product or your device and will void your warranty.

- This keyboard is suitable for Bluetooth enabled devices with version 5.0
- Use only charging devices that meet the required technical specifications in order to avoid malfunctions or damage to the product.
- Please make sure that the socket is always easily accessible when the keyboard is charging.
- The device may get warm during charging. This is normal.
- Do not use excessive force when connecting or removing the cable. Using excessive force may damage the cable or port.
- Do not open the product and do not attempt to repair the product yourself. Doing so puts you at risk of injury or causing damage to the device and will void your warranty.
- Do not insert any object into the port that is not designed for this purpose.
- Avoid subjecting the product to heavy shocks and protect it against impacts and falls at all times.
- Do not use the product and accessories if there is any visible damage, if it has come into contact with water or other fluids, or if it is damp.
- Keep the device out of direct sunlight and do not use in the immediate vicinity of any heat sources.
- Keep the product away from open fire. Danger of explosion!
- Keep the product away from water, other fluids and fire at all times.
- Do not use the product in extremely cold, hot, damp or dusty areas.
- Operate this product only in a dry environment between 0°C and 35°C only.
- Do not operate this product in areas and places where the use of electronic equipment is not permitted.
- If you do not intend to use the product for a longer period of time, store it at a temperature between -10 and 35 degrees Celsius with a maximum relative humidity of 85% (for short periods). Fully charge the battery every three months in order to maintain battery performance.
- Obstructions, such as walls, may influence the keyboards' transmitting range. To ensure a good connection, we suggest to avoid such obstructions as good as possible and/or lower the distance during operation.
- If the product does not operate properly, turn it on again, disconnect the connection from your device and reconnect it after a moment.
- The illustrations in this manual are for descriptive purposes only and do not show a detailed description.
- Product images may vary from the actual product. The content of this user manual may be revised without prior notice.
- To improve products performance, the content of this user manual may be revised without prior notice.
- The mode of operation in here, is depending on the device and may work differently as described.

Notes: You can pair a single device to the keyboard only. Once a device has been successfully connected, it will connect automatically with the keyboard at the next time. The keyboard will disconnect if you are out of the transmitting range of 10m and will reconnect once both devices are in range again. The keyboard turns off automatically when the charge level is less than 3%. Recharge the battery.



ΣΥΜΠΑΓΕΣ ΚΑΙ ΜΟΝΤΕΡΝΟ ΠΛΗΚΤΡΟΛΟΓΙΟ ΜΕ 63 ΠΛΗΚΤΡΑ ΚΑΙ TOUCHPAD ΚΑΙ ΛΕΙΤΟΥΡΓΙΚΑ ΠΛΗΚΤΡΑ ΓΙΑ ΑΜΕΣΩΣ ΤΠΡΟΒΑΣΗ ΣΙΣ ΔΕΙΓΜΟΓΕΣ ΣΧΕΔΙΑΣΜΕΝΟ ΕΙΔΙΚΑ ΓΙΑ BLUETOOTH ΣΥΣΚΕΥΕΣ

Item no.: MROS130-GR

Η διάταξη του πληκτρολογίου που εμφανίζεται σε αυτό το εγχειρίδιο μπορεί να διαφέρει από το προϊόν της συσκευασίας.
Μπορείτε να ανταρτέστε στην ετικέτα της συσκευασίας για λεπτομέρειες.

EN Package contents

- 1x MediaRange Compact-sized wireless keyboard with 63 keys and touchpad, black
- 1x approx. 50cm USB-A to micro USB cable
- 1x User manual, Operating- and safety instructions and warranty conditions (DE/EN)

EN Operating- and safety instructions

Please read the following operation and safety instructions carefully before using this product to ensure safe and proper use. If these instructions are not followed, you may damage this product or your device and will void your warranty.

- This keyboard is suitable for Bluetooth enabled devices with version 5.0
- Use only charging devices that meet the required technical specifications in order to avoid malfunctions or damage to the product.
- Please make sure that the socket is always easily accessible when the keyboard is charging.
- The device may get warm during charging. This is normal.
- Do not use excessive force when connecting or removing the cable. Using excessive force may damage the cable or port.
- Do not open the product and do not attempt to repair the product yourself. Doing so puts you at risk of injury or causing damage to the device and will void your warranty.
- Do not insert any object into the port that is not designed for this purpose.
- Avoid subjecting the product to heavy shocks and protect it against impacts and falls at all times.
- Do not use the product and accessories if there is any visible damage, if it has come into contact with water or other fluids, or if it is damp.
- Keep the device out of direct sunlight and do not use in the immediate vicinity of any heat sources.
- Keep the product away from open fire. Danger of explosion!
- Keep the product away from water, other fluids and fire at all times.
- Do not use the product in extremely cold, hot, damp or dusty areas.
- Operate this product only in a dry environment between 0°C and 35°C only.
- Do not operate this product in areas and places where the use of electronic equipment is not permitted.
- If you do not intend to use the product for a longer period of time, store it at a temperature between -10 and 35 degrees Celsius with a maximum relative humidity of 85% (for short periods). Fully charge the battery every three months in order to maintain battery performance.
- Obstructions, such as walls, may influence the keyboards' transmitting range. To ensure a good connection, we suggest to avoid such obstructions as good as possible and/or lower the distance during operation.
- If the product does not operate properly, turn it on again, disconnect the connection from your device and reconnect it after a moment.
- The illustrations in this manual are for descriptive purposes only and do not show a detailed description.
- Product images may vary from the actual product. The content of this user manual may be revised without prior notice.
- To improve products performance, the content of this user manual may be revised without prior notice.
- The mode of operation in here, is depending on the device and may work differently as described.

Notes: You can pair a single device to the keyboard only. Once a device has been successfully connected, it will connect automatically with the keyboard at the next time. The keyboard will disconnect if you are out of the transmitting range of 10m and will reconnect once both devices are in range again. The keyboard turns off automatically when the charge level is less than 3%. Recharge the battery.



ΣΥΜΠΑΓΕΣ ΚΑΙ ΜΟΝΤΕΡΝΟ ΠΛΗΚΤΡΟΛΟΓΙΟ ΜΕ 63 ΠΛΗΚΤΡΑ ΚΑΙ TOUCHPAD ΚΑΙ ΛΕΙΤΟΥΡΓΙΚΑ ΠΛΗΚΤΡΑ ΓΙΑ ΑΜΕΣΩΣ ΤΠΡΟΒΑΣΗ ΣΙΣ ΔΕΙΓΜΟΓΕΣ ΣΧΕΔΙΑΣΜΕΝΟ ΕΙΔΙΚΑ ΓΙΑ BLUETOOTH ΣΥΣΚΕΥΕΣ

Item no.: MROS130-GR

Η διάταξη του πληκτρολογίου που εμφανίζεται σε αυτό το εγχειρίδιο μπορεί να διαφέρει από το προϊόν της συσκευασίας.
Μπορείτε να ανταρτέστε στην ετικέτα της συσκευασίας για λεπτομέρειες.

EN Package contents

- 1x MediaRange Compact-sized wireless keyboard with 63 keys and touchpad, black
- 1x approx. 50cm USB-A to micro USB cable
- 1x User manual, Operating- and safety instructions and warranty conditions (DE/EN)

EN Operating- and safety instructions

Please read the following operation and safety instructions carefully before using this product to ensure safe and proper use. If these instructions are not followed, you may damage this product or your device and will void your warranty.

- This keyboard is suitable for Bluetooth enabled devices with version 5.0
- Use only charging devices that meet the required technical specifications in order to avoid malfunctions or damage to the product.
- Please make sure that the socket is always easily accessible when the keyboard is charging.
- The device may get warm during charging. This is normal.
- Do not use excessive force when connecting or removing the cable. Using excessive force may damage the cable or port.
- Do not open the product and do not attempt to repair the product yourself. Doing so puts you at risk of injury or causing damage to the device and will void your warranty.
- Do not insert any object into the port that is not designed for this purpose.
- Avoid subjecting the product to heavy shocks and protect it against impacts and falls at all times.
- Do not use the product and accessories if there is any visible damage, if it has come into contact with water or other fluids, or if it is damp.
- Keep the device out of direct sunlight and do not use in the immediate vicinity of any heat sources.
- Keep the product away from open fire. Danger of explosion!
- Keep the product away from water, other fluids and fire at all times.
- Do not use the product in extremely cold, hot, damp or dusty areas.
- Operate this product only in a dry environment between 0°C and 35°C only.
- Do not operate this product in areas and places where the use of electronic equipment is not permitted.
- If you do not intend to use the product for a longer period of time, store it at a temperature between -10 and 35 degrees Celsius with a maximum relative humidity of 85% (for short periods). Fully charge the battery every three months in order to maintain battery performance.
- Obstructions, such as walls, may influence the keyboards' transmitting range. To ensure a good connection, we suggest to avoid such obstructions as good as possible and/or lower the distance during operation.
- If the product does not operate properly, turn it on again, disconnect the connection from your device and reconnect it after a moment.
- The illustrations in this manual are for descriptive purposes only and do not show a detailed description.
- Product images may vary from the actual product. The content of this user manual may be revised without prior notice.
- To improve products performance, the content of this user manual may be revised without prior notice.
- The mode of operation in here, is depending on the device and may work differently as described.

Notes: You can pair a single device to the keyboard only. Once a device has been successfully connected, it will connect automatically with the keyboard at the next time. The keyboard will disconnect if you are out of the transmitting range of 10m and will reconnect once both devices are in range again. The keyboard turns off automatically when the charge level is less than 3%. Recharge the battery.



ΣΥΜΠΑΓΕΣ ΚΑΙ ΜΟΝΤΕΡΝΟ ΠΛΗΚΤΡΟΛΟΓΙΟ ΜΕ 63 ΠΛΗΚΤΡΑ ΚΑΙ TOUCHPAD ΚΑΙ ΛΕΙΤΟΥΡΓΙΚΑ ΠΛΗΚΤΡΑ ΓΙΑ ΑΜΕΣΩΣ ΤΠΡΟΒΑΣΗ ΣΙΣ ΔΕΙΓΜΟΓΕΣ ΣΧΕΔΙΑΣΜΕΝΟ ΕΙΔΙΚΑ ΓΙΑ BLUETOOTH ΣΥΣΚΕΥΕΣ

Item no.: MROS130-GR

Η διάταξη του πληκτρολογίου που εμφανίζεται σε αυτό το εγχειρίδιο μπορεί να διαφέρει από το προϊόν της συσκευασίας.
Μπορείτε να ανταρτέστε στην ετικέτα της συσκευασίας για λεπτομέρειες.

EN Package contents

- 1x MediaRange Compact-sized wireless keyboard with 63 keys and touchpad, black
- 1x approx. 50cm USB-A to micro USB cable
- 1x User manual, Operating- and safety instructions and warranty conditions (DE/EN)

EN Operating- and safety instructions

Please read the following operation and safety instructions carefully before using this product to ensure safe and proper use. If these instructions are not followed, you may damage this product or your device and will void your warranty.

- This keyboard is suitable for Bluetooth enabled devices with version 5.0
- Use only charging devices that meet the required technical specifications in order to avoid malfunctions or damage to the product.
- Please make sure that the socket is always easily accessible when the keyboard is charging.
- The device may get warm during charging. This is normal.
- Do not use excessive force when connecting or removing the cable. Using excessive force may damage the cable or port.
- Do not open the product and do not attempt to repair the product yourself. Doing so puts you at risk of injury or causing damage to the device and will void your warranty.
- Do not insert any object into the port that is not designed for this purpose.
- Avoid subjecting the product to heavy shocks and protect it against impacts and falls at all times.
- Do not use the product and accessories if there is any visible damage, if it has come into contact with water or other fluids, or if it is damp.
- Keep the device out of direct sunlight and do not use in the immediate vicinity of any heat sources.
- Keep the product away from open fire. Danger of explosion!
- Keep the product away from water, other fluids and fire at all times.
- Do not use the product in extremely cold, hot, damp or dusty areas.
- Operate this product only in a dry environment between 0°C and 35°C only.
- Do not operate this product in areas and places where the use of electronic equipment is not permitted.
- If you do not intend to use the product for a longer period of time, store it at a temperature between -10 and 35 degrees Celsius with a maximum relative humidity of 85% (for short periods). Fully charge the battery every three months in order to maintain battery performance.
- Obstructions, such as walls, may influence the keyboards' transmitting range. To ensure a good connection, we suggest to avoid such obstructions as good as possible and/or lower the distance during operation.
- If the product does not operate properly, turn it on again, disconnect the connection from your device and reconnect it after a moment.
- The illustrations in this manual are for descriptive purposes only and do not show a detailed description.
- Product images may vary from the actual product. The content of this user manual may be revised without prior notice.
- To improve products performance, the content of this user manual may be revised without prior notice.
- The mode of operation in here, is depending on the device and may work differently as described.

Notes: You can pair a single device to the keyboard only. Once a device has been successfully connected, it will connect automatically with the keyboard at the next time. The keyboard will disconnect if you are out of the transmitting range of 10m and will reconnect once both devices are in range again. The keyboard turns off automatically when the charge level is less than 3%. Recharge the battery.



ΣΥΜΠΑΓΕΣ ΚΑΙ ΜΟΝΤΕΡΝΟ ΠΛΗΚΤΡΟΛΟΓΙΟ ΜΕ 63 ΠΛΗΚΤΡΑ ΚΑΙ TOUCHPAD ΚΑΙ ΛΕΙΤΟΥΡΓΙΚΑ ΠΛΗΚΤΡΑ ΓΙΑ ΑΜΕΣΩΣ ΤΠΡΟΒΑΣΗ ΣΙΣ ΔΕΙΓΜΟΓΕΣ ΣΧΕΔΙΑΣΜΕΝΟ ΕΙΔΙΚΑ ΓΙΑ BLUETOOTH ΣΥΣΚΕΥΕΣ

Item no.: MROS130-GR

Η διάταξη του πληκτρολογίου που εμφανίζεται σε αυτό το εγχειρίδιο μπορεί να διαφέρει από το προϊόν της συσκευασίας.
Μπορείτε να ανταρτέστε στην ετικέτα της συσκευασίας για λεπτομέρειες.

EN Package contents

- 1x MediaRange Compact-sized wireless keyboard with 63 keys and touchpad, black
- 1x approx. 50cm USB-A to micro USB cable
- 1x User manual, Operating- and safety instructions and warranty conditions (DE/EN)

EN Operating- and safety instructions

Please read the following operation and safety instructions carefully before using this product to ensure safe and proper use. If these instructions are not followed, you may damage this product or your device and will void your warranty.

- This keyboard is suitable for Bluetooth enabled devices with version 5.0
- Use only charging devices that meet the required technical specifications in order to avoid malfunctions or damage to the product.
- Please make sure that the socket is always easily accessible when the keyboard is charging.
- The device may get warm during charging. This is normal.
- Do not use excessive force when connecting or removing the cable. Using excessive force may damage the cable or port.
- Do not open the product and do not attempt to repair the product yourself. Doing so puts you at risk of injury or causing damage to the device and will void your warranty.
- Do not insert any object into the port that is not designed for this purpose.
- Avoid subjecting the product to heavy shocks and protect it against impacts and falls at all times.
- Do not use the product and accessories if there is any visible damage, if it has come into contact with water or other fluids, or if it is damp.
- Keep the device out of direct sunlight and do not use in the immediate vicinity of any heat sources.
- Keep the product away from open fire. Danger of explosion!
- Keep the product away from water, other fluids and fire at all times.
- Do not use the product in extremely cold, hot, damp or dusty areas.
- Operate this product only in a dry environment between 0°C and 35°C only.
- Do not operate this product in areas and places where the use of electronic equipment is not permitted.
- If you do not intend to use the product for a longer period of time, store it at a temperature between -10 and 35 degrees Celsius with a maximum relative humidity of 85% (for short periods). Fully charge the battery every three months in order to maintain battery performance.
- Obstructions, such as walls, may influence the keyboards' transmitting range. To ensure a good connection, we suggest to avoid such obstructions as good as possible and/or lower the distance during operation.
- If the product does not operate properly, turn it on again, disconnect the connection from your device and reconnect it after a moment.
- The illustrations in this manual are for descriptive purposes only and do not show a detailed description.
- Product images may vary from the actual product. The content of this user manual may be revised without prior notice.
- To improve products performance, the content of this user manual may be revised without prior notice.
- The mode of operation in here, is depending on the device and may work differently as described.

Notes: You can pair